

ایمن باش ایمنی، آتش نشانی، ابزار دقیق، کالیبراسیون، آدرس تلفن: ۰۲۱-۶۶۹۶۵۱۳۹

SAFETY TRIPOD
TM 13



+۹۸ ۹۹۰ ۱۳۶۵ ۳۴۲

<https://imanbash.ir>

info@imanbash.ir

ایمن باش ایمنی، آتش نشانی، ابزار دقیق، کالیبراسیون، آموزش تلفن: ۰۲۱-۶۶۹۶۵۱۳۹




+۹۸ ۹۹۰ ۱۳۶۵ ۳۴۲

<https://imanbash.ir>

info@imanbash.ir

ایمن باش ایمنی، آتش نشانی، ابزار دقیق، کالیبراسیون، آموزش تلفن: ۰۲۱-۶۶۹۶۵۱۳۹



+۹۸ ۹۹۰ ۱۳۶۵ ۳۴۲

<https://imanbash.ir>

info@imanbash.ir

edition: 3/09.12.2013

SAFETY TRIPOD TM-13

nr ref.: AT-015


Safety Tripod TM 13 is a component of personal protective equipment against fall from height. It is used as portable anchor point. Safety tripod TM13 has to be used in conjunction with fall arrest equipment.

Safety tripod TM13 has been tested according to EN 795 and TS 16415 as a transportable temporary anchorage device type B.

Safety Tripod TM13 provides protection for maximum two people at the same time.

Device head is equipped with two wheels provides rope guidance when RUP 502-A or RUP 503 or CR W300+AT172 devices are used.
Head is equipped with three Side Attachment Points.



Telescopic legs allow to adjust tripod's height (9 steps). Each of leg "A" are equipped with Legs Attachment Point for using with RUP 503 lifting devices or with CRW 300 retractable type fall arrester (with additional Adaptor - AT172). Leg "B" (without wheel on the head) is not equipped with attachment point.



Additional Stairs can be used for easier working rope installation on the safety tripod head when the legs are fully extended (recomended min. 3 pcs.)

Pin prevent working
rope against
accidental falling
from wheel.

Built-in wheels for working rope guidance.




Steel foot with holes for install support chain. Thorns for better transtion on slippery surfaces (e.g. ice, snow ect.).

Working Height	: 179...289 cm
Legs Spacing	: 147...232 cm
Diameter over which it can deploy a tripod	: 173...271 cm

- Working Load Limit : depends on using equipment,
- Protection for maximum two people at the same time,
- Available 5 Attachment Points,
- Aluminium alloy legs,
- Additional steps (min. 3 pcs.) - see Detail A,
- Head with built-in wheels for working rope guidance,
- Designed to use with: RUP 502-A / RUP 503 / CRW 300+AT172 rescue lifting devices.
- Shipping dimensions: 200 x 33 x 31 cm,
- Weight: 37 kg.

EN 795:2013/B; TS 16415:2013/B



ایمن باش ایمنی، آتش نشانی، ابزار دقیق، کالیبراسیون، آموزش تلفن: ۰۲۱-۶۶۹۶۵۱۳۹



**WINCH
RUP 503**

+۹۸ ۹۹۰ ۱۳۶۵ ۳۴۲

[Https://imanbash.ir](https://imanbash.ir)

info@imanbash.ir

DESIGNATED USE

The rescue lifting device RUP 503-[...] series is a component of rescue system. Using this device the rescuer can lift the other person from a lower to higher place or lower him from a higher to lower place. Lowering distance is limited to 2 meters. The RUP 503-[...] series device complies with EN 1496:2006 / B.


Description of RUP 503-[...] series rescue lifting devices:

- RUP 503 - lifting device with grip for mounting on the tripods: TM6 / TM11 / TM12 / TM12-2 / TM13
- RUP 503-B - lifting device with grip for mounting on the tripod: TM7


sign "xx" - standard working rope length in meters (25, 35, 45, 50m)

TECHNICAL DATA


Working load limit:	200 kg
hand force required:	10 kg
Gear ratio:	7.2:1
Reel diameter:	60 mm
Crank length:	300 mm
Rope diameter:	Ø 6,3 mm
Weight:	rope 25 m - 22,5 kg rope 35 m - 24,0 kg rope 45 m - 25,5 kg rope 50 m - 26,2 kg




1. Open the grip.



2. Put the device on the tripod's leg. Grip locking pin must be fastened on the locking hole situated on the outside part of the tripod's leg.




3. Close grip. Lock the grip using the lever. Grease the lever's thread with small amount of constant lubricant before installation. The winch shall not slide on the tripod's leg.




CAUTION!

Ensure that locking is properly fitted into locking hole. Locking pin prevents against device sliding on the tripod's leg.



CORRECT !
Locking pin mounted
in the locking hole



WRONG !
Locking pin outside
the locking hole


LIFTING AND LOWERING

این وسیله آتش نشانی، ابزار دقیق، کالیبراسیون / آزمون فقط برای اهداف نجاتی و نه برای بلند کردن / پایین آوردن بارها.

Lifting must happen by set change lever in UP position then rotating the crank clock-wise or operate crank back and forth to move load in up direction.

If the lever will be released while lifting the load will be suspended in place.

The descent must happen by set change lever in DOWN position then rotating the crank counterclock-wise or operate handle back and forth to move load in down direction.




INSTALLING DEVICE ON A STRUCTURAL ANCHOR ELEMENT


It is possible to install device directly on the structural anchor element like flat surface (e.g. wall) or steel profile. The structural anchor element to which the device is fastened must have stable construction and have minimal static strength of 20 kN. Construction and fastening of the structural anchor element must prevent of accidental disconnection of the device. To install device on the structural anchor element the grip which is designed to be used only with the tripod must be removed.

REMOVING THE GRIP

1. Unscrew two M12 nuts fastening the grip to the winch.





2. Remove the bolts and the washers. Remove the grip.




INSTALLING ON THE FLAT SURFACE (MECHANICAL / CHEMICAL ANCHORS)

1. Device should be installed using four $\varnothing 13$ mm holes situated on the back wall of the winch.
2. Install winch using four M12 steel mechanical or chemical anchor bolts. Anchors should be installed in accordance with the installation instructions provided by the manufacturer of the anchors.
3. Put the washer $\varnothing 13$ (DIN 125A) under each nut. Tighten four M12 self-locking nuts (DIN 985).




INSTALLING ON THE FLAT SURFACE (SCREWS)

1. Device should be installed using four $\varnothing 13$ mm holes situated on the back wall of the winch.
2. Install device using four M12 steel bolts. Put the bolts through the back wall of the winch and through the holes of the structural anchor surface.
3. Put the washers $\varnothing 13$ mm (DIN 125A) under the head of each bolt and under each nut. Tighten four M12 self-locking nuts (DIN 985).





INSTALLING ON THE STEEL PROFILE

1. To the narrow structural elements the winch should be mounted using two oblong holes (35 mm length) with a diameter $\varnothing 13$ mm located in back winch wall.
2. Device should be installed using two M12 steel bolts. Put the bolts through the back wall of the winch and through the structural anchor profile.
3. Put the washers $\varnothing 13$ mm (DIN 125A) under the head of each bolt and under each nut. Tighten two M12 self-locking nuts (DIN 985).



POSITIONING OF THE DEVICE


1. Check the proper position of the device and correct guiding of the rope shown on the pictures below.
2. The construction element where the winch is installed must be vertical or horizontal.
3. Attach the energy absorber to the cable using the connector supplied with the absorber.
4. Connect absorber's connector to the attachment element of a harness. Use "A" frontal or dorsal attachment point in full body harness (EN 361) or rescue attachment point in rescue harness (EN 1497) or rescue loops (EN 1498).



CAUTION!



تلفن: ۰۲۱-۶۶۹۶۸۱۳۹

- ایمنی آتش نشانی، ایمنی برق، کالیبراسیون، آموزش
- Rescue device mechanism is lubricated and sealed. No lubrication of the mechanism is necessary after the use of the device.
 - It is forbidden to lubricate rescue device emergency brake mechanism!!!
 - It is forbidden to use the rescue lifting device as the protection against falls from height. When there is a danger of falling from a height additional secondary fall arrest system conforming EN 363 must be used.
 - The lifting / lowering function is for rescue purposes only and not for lifting / lowering loads.
 - Always operate the device with hand power and with crank included in the equipment only.
 - Before each use of rescue device a thorough inspection must be carried out. Inspection must be carried out by a person using the device. In the case of damages and malfunctions, the device should be withdrawn from use.
 - Never allow to full extension of the working rope from the reel. Keep at least three rope coils on the reel - it is marked by a special safety sign which is situated on the rope. Stop extend the rope from the reel when the red safety sign appears! Obligatory check a condition of the safety sign.
 - There should be direct or indirect visual contact or some other means of communication with the rescuer at all times during the rescue process.
 - Using the device, in connection with fall arrest system, must be compatible with manual instructions of the fall arrest systems and obligatory standards: EN 361, EN 1497, EN 1498, EN 341 - for body holding devices; EN 795 - for anchor devices; EN 353-1, EN 353-2, EN 354, EN 355, EN 360 - for fall arrest systems, EN 362 - for the connectors.



THE ESSENTIAL PRINCIPLES OF USE PERSONAL PROTECTIVE EQUIPMENT

- Personal protective equipment (PPE) shall only be used by a person trained and competent in its safe use.
- PPE must not be used by a person with medical condition that could affect the safety of the equipment user in normal and emergency use.
- A rescue plan shall be in place to deal with any emergencies that could arise during the work.
- It is forbidden to make any alterations and additions to the equipment without manufacturer's prior written consent.
- Any repairs shall only be carried out by equipment manufacturer or his certified representative.
- PPE shall not be used outside its limitations, or of any purpose other than that for which it is intended.
- PPE should be a personal issue item.
- Before use ensure about the compatibility of items of equipment assembled into a fall arrest system. Periodically check connecting and adjusting of the equipment components to avoid accidental loosening or disconnecting of the components.
- It is forbidden to use combinations of items of equipment in which the safe function of any one item is affected by or interferes with the safe function of another.
- There are many hazards that may affect the performance of the equipment and corresponding safety precautions that have to be observed during equipment utilization, especially: (trailing or looping of lanyards or lifelines over sharp edges; any defects like cutting, abrasion, corrosion; climatic exposure; pendulum falls; extremes of temperature; chemical reagents; electrical conductivity).
- A full body harness conformed to EN 361 is the only acceptable body holding device that can be used in a fall arrest system.
- The anchor device or anchor point for the fall arrest system should always be positioned, and the work carried out in such a way, as to minimise both the potential for falls and potential fall distance. The anchor device/point should be placed above the user. The shape and construction of the anchor device/point shall not allowed to self-acting disconnection of the equipment. It is recommended to use certified and marked structural anchor point complied with EN 795.
- It is obligatory to verify the free space required beneath the user at the workplace before each occasion of use the fall arrest system, so that, in the case of a fall, there will be no collision with the ground or other obstacle in the fall path. The required value of the free space should be taken from instruction manual of used equipment.
- Using the energy absorber in conjunction with other elements of PPE must conform to the appropriate regulations and instruction manuals and current standards: EN 361 - for harnesses; EN 353-1, EN 353-2, EN 354, EN 360, EN 362 - for fall arrest systems; EN 795 - for structural anchor points/devices.
- In full body harnesses use only attaching points marked with big letter "A" to attach a fall arrest system. See the figures below:



INSPECTION

Before each use of Personal Protective Equipment (PPE) it is obligatory to carry out a pre-use check of the equipment, to ensure that it is in a serviceable condition and operates correctly before it is used.

During pre-use check it is necessary to inspect all elements of the equipment in respect of any damages, excessive wear, corrosion, abrasion, cutting or incorrect acting, especially in rescue lifting devices - cable (wires, clips, ferrules, loops, thimbles, connectors, adjusting elements) and automatic brake proper acting, casing, energy absorber (attaching loops, connectors), connectors (main body, rivets, gate, locking gear acting).

PERIODIC INSPECTION

After each 12 months of utilization the rescue lifting device must be withdrawn from use to carry out manufacturer's detailed inspection. The inspection must be carried out by the rescue lifting device manufacturer or his certified representative only. During this inspection will be established admissible time of the device use till next manufacturer's inspection.

The result of inspection must be recorded in Identity Card.

Regular periodic inspections are the essential for equipment maintenance and the safety of the users which depends upon the continued efficiency and durability of the equipment.

During periodic inspections it is necessary to check the legibility of the equipment marking.

It is essential for the safety of the user that if the product is re-sold outside the original country of destination the reseller shall provide instruction for use, for maintenance, for periodic examination and for repair in language of the country in which the product is to be used.

WITHDRAWAL FROM USE

Personal protective equipment must be withdrawn from use immediately when any doubt arise about its condition for safe use and not used again until confirmed in writing by equipment manufacturer or his certified representative after carried out the detailed inspection.

WITHDRAWAL FROM USE AFTER ARREST A FALL

Personal protective equipment must be immediately withdrawn from use when it has been component of equipment used to arrest a fall. After that the detailed manufacturer's inspection must be carried out.

Detailed manufacturer's inspection can be carried out by:

- equipment manufacturer;
- or person recommended by manufacturer
- a company recommended by manufacturer.

During this inspection will be established if the device can be longer used and will be define the admissible time of device use till next manufacturer's inspection. If the device can not be longer used it will be subjected to destroyed.

TRANSPORTATION

PPE must be transported in the package (e.g. bag made of moisture-proof textile or foil bag or cases made of steel or plastic) to protect it against damage or moisture.

MAINTENANCE AND STORAGE



PPE can be cleaned and disinfected without causing adverse effect on the materials in the manufacture the equipment. For textile products use mild detergents for delicate fabrics, wash by hand or in a machine and rinse in water. Plastic parts can be cleaned only with water. When the equipment becomes wet, either from being in use or when due cleaning, it shall be allowed to dry naturally, and shall be kept away from direct heat. In metallic products some mechanic parts (spring, pin, hinge, etc.) can be regularly slightly lubricated to ensure better operation.

PPE should be stored loosely packed, in a well-ventilated place, protected from direct light, ultraviolet degradation, damp environment, sharp edges, extreme temperatures and corrosive or aggressive substances.

CONTENT OF THE IDENTITY LABEL

- ایمنی ، آتش نشانی ، ابزار دقیق ، کالیبراسیون ، آموزش
- ایمن باش
- a) Device type.
 - b) Model symbol.
 - c) Reference number.
 - d) Number/year/class of the European standard.
 - e) Rescue equipment - information.
 - f) Month and year of manufacture.
 - g) Serial number of the tripod.
 - h) Caution: read the manual.
 - i) Marking of the manufacturer or distributor of the tripod.
 - j) Maximum load limit.

The Notified Body involved with EC type examination and in the production control phase: APAVE SUDEUROPE SAS, BP 193, 13322 Marseille, France.



IDENTITY CARD

IT IS RESPONSIBILITY OF THE USER ORGANISATION TO PROVIDE THE IDENTITY CARD AND TO FILL IN THE DETAILS REQUIRED. THE IDENTITY CARD SHOULD BE FILLED IN ONLY BY COMPETENT PERSON RESPONSIBLE FOR PROTECTIVE EQUIPMENT. THE IDENTITY CARD SHOULD BE FILLED IN BEFORE THE FIRST USE OF THE EQUIPMENT. ANY INFORMATION ABOUT THE EQUIPMENT LIKE: PERIODIC INSPECTIONS, REPAIRS, REASONS OF EQUIPMENT'S WITHDRAWN FROM USE SHALL BE NOTED. THE IDENTITY CARD SHOULD BE STORED DURING A WHOLE PERIOD OF EQUIPMENT UTILIZATION. DO NOT USE THE EQUIPMENT WITHOUT THE IDENTITY CARD.

MODEL AND TYPE OF EQUIPMENT	
REF. NUMBER	
SERIAL NUMBER	
DATE OF MANUFACTURE	
DATE OF PURCHASE	
DATE OF FIRST USE	
USER NAME	

PERIODIC EXAMINATION AND REPAIR HISTORY

	DATE	REASON FOR SERVICING / REPAIR	REPAIRS CARRIED OUT	NAME AND SIGNATURE OF COMPETENT PERSON	DATE OF NEXT EXAMINATION
1					
2					
3					
4					
5					
6					
7					
8					
9					

PRODUCER:

PROTEKT, 93-403 LODZ, ul. Starorudzka 9, POLAND, tel: +48 (42) 680 20 83, fax: +48 (42) 680 20 93, www.protekt.com.pl



Centre d'Essais de Fontaine
17, Boulevard Paul Langevin
38600 FONTAINE - France
Tél. +33.(0)4.76.53.52.22
Fax +33.(0)4.76.53.32.40

CERTIFICATE OF CONFORMITY N°13.6.0513/G

I. APPLICANT

- Applicant: Mr Grzegorz Laszkiewicz
- Company: PROTEKT Grzegorz Laszkiewicz - Ul. Starorudzka 9 - 93-403 LODZ - Poland

II. MATERIAL CONSIDERED

- Type of equipment: Rescue lifting devices EN 1496:2006 - Class B
- Trade mark: **PROTEKT**
- Model: **TM13 + RUP 503**
- Reference: **TM13 + AT053 xx** (xx= length code from 25m to 50m)

III. REFERENTIAL USED

- The assessment of conformity was conducted taking also into account the provisions of European standard EN 1496 of November 2006 "Personal fall protection equipment – Rescue lifting devices".

IV. CONDITION FOR USE OF THE EQUIPMENT

- This rescue lifting device of class B is intended to be used, in combination with other components, as personal protective equipment against falls from a height planned for the rescue operation.

V. DESCRIPTION

- Rescue lifting and lowering device class B, with stainless steel wire rope including natural fiber core, section 6x19, and diameter 6.3mm, length from 25m to 50m with automatic brake. Thimble sleeved buckle on the end of the wire cable with a connector reference AZ011, an absorbing spring reference SDW.00.01 and a winch absorber reference SDW.00.00 and a connector reference AZ011. To use mounted on the tripod TM6 / TM11 / TM12 / TM12-2 / TM13 by a clamp device ref. AT014-300. Down function is only intended to lower a person over a distance of 2 m. Maximal working load: 200kg

VI. CONCLUSION

- The rescue lifting device "**PROTEKT**", model "**TM13**" + "**RUP 503**", reference "**TM13**" + "**AT053 xx** (xx= length code from 25m to 50m)" as defined in the report of conformity n° 13.6.0513 is conform to the requirements of the standard EN 1496 of November 2006 and with the conformity of manufacturer's technical file.

Authenticated with APAVE SUDEUROPE stamp

Date: the 19th January 2015

PPE Technical Manager


APAVE SUDEUROPE
CENTRE D'ESSAIS DE FONTAINE
17 boulevard Paul Langevin
38600 FONTAINE
Tél. 04 76 53 52 22 - Fax 04 76 53 32 40


Emine Cengiz

This conformity certificate is not an EC Type examination delivered by a Notified Body.

This certificate includes one page. This certificate is edited in two original copies. No duplicate will be issued.

APAVE SUDEUROPE SAS Siège social : 8 rue Jean-Jacques Vernazza - Z.A.C. Saumaty-Séon - CS 60193 - 13322 MARSEILLE CEDEX 16
Tél. : 04 96 15 22 60 - Fax : 04 96 15 22 61 - Site Internet : www.apave.com
Société par Actions Simplifiée au Capital de 6 648 544 € - N° SIREN : 518 720 925